

G. TRIM TAB INSTALLATION

- G1. Using the reference holes you drilled in the bottom elevator skin as guides, saw out the trim tab from the elevator. A hand held hack saw blade works well for cutting through top and bottom skin at one time. Notice that your hingeline cut in the top elevator skin should be parallel to the hinge line of the elevator.



LANCAIR 320 FB-MK-II

7(B)-40

Chapter 7(B) REV. 1/1-24-94

HORIZONTAL STAB & ELEVATOR

Lancair International, Inc. - Represented by Vista Aviation Inc. Copyright © 1994, Revised, 08-11700