

- G2. Cut a 20" piece of MS2001-5 hinge.
- G3. Sand the edges you have just cut straight. Fit the hinge to the trim tab and the elevator so the T.E. of the tab is in line with the T.E. of the elevator. You will have to sand the L.E. of the trim tab and the elevator (only in the trim tab area!) to allow the tab to achieve full "up" travel. Don't get confused here, "up" trim tab movement will force the elevator down, thus trimming the aircraft nose down. See Figure 7b;G:2.



**LANCAIR** 320 FB- MK-II

7(B)-42

Chapter 7(B) REV. 1 / 1-24-94  
HORIZONTAL STAB & ELEVATOR

Canair International Inc., Represented by New Aviation Inc., Copyright © 1994, Redwood, OR 97154