


**ASSEMBLY MANUAL**  
**FOR THE LANCAIR LEGACY**



1-1

Chapter 1 | REV. 0/02-15-02

INTRODUCTION



1-2

<b>Chapter 1</b>	REV.	0/02-15-02
<b>INTRODUCTION</b>		

# Contents

<b>Chapter 1: Introduction.....</b>	<b>1-3</b>
1. INTRODUCTION .....	1-4
A. Recommended Background Information .....	1-4
B. Manual Layout and Use .....	1-7
Chapter Organization.....	1-7
Revisions .....	1-7
C. Setting Up Your Shop .....	1-7
Cutting Tables .....	1-7
D. Terms and Definitions .....	1-8
E. Structural Adhesive .....	1-10
F. AN- Bolt and Hardware Guide .....	1-11
G. Basic Shop Tools .....	1-14
Specialized Tools .....	1-16
Supplies .....	1-19
H. Premolded Parts - Exploded View .....	1-21
Premolded Parts List - not included in figure .....	1-22
I. Procedures .....	1-23
Cleaning, care, and handling of parts .....	1-23
J. Joint Description .....	1-23
K. Trimming Procedure .....	1-24
L. Drilling Alignment Holes .....	1-25
M. Removing the Protective Coating - Peelply .....	1-25
N. Fastening Parts Together .....	1-27
O. Fiberglass Strip Installation .....	1-30
P. Cutting on the Bias .....	1-31
Q. The Plastic Sandwich .....	1-32
R. Tongue Depressors and Micro Radii .....	1-33
About those Micro Radii .....	1-34
S. Those Annoying 2"-Wide Bid Tapes .....	1-35
T. Cardboard Templates .....	1-35
U. Building Light .....	1-35
V. Building Straight .....	1-36
Straight Trailing Edges .....	1-36

W. Control Systems .....	1-38
Pushrod Tips .....	1-38
X. Hydraulic Systems .....	1-40
Tube flaring .....	1-41
Y. Painting .....	1-43
Z. Building a Jack Stand .....	1-45

## Chapter 2: Horizontal Stabilizer and Elevator ..... 2-1

1. INTRODUCTION .....	2-1
2. PARTS LIST .....	2-1
3. CONSTRUCTION PROCEDURES .....	2-3
A. Building the Horizontal Stabilizer Assembly Cradle .....	2-3
B. Horizontal Stabilizer Hinge Brackets .....	2-6
C. Elevator Hinge Installation .....	2-7
D. Elevator Trim Tab .....	2-10
Setting the Trim Tab .....	2-10
E. Couterbalancing the Elevators .....	2-11
F. Closing the Horizontal Stabilizer and Elevator .....	2-12
Closing the Elevators .....	2-13
G. Elevator Travel Stops .....	2-14

## Chapter 3: Wing Systems ..... 3-1

1. INTRODUCTION .....	3-1
2. PARTS LIST .....	3-1
3. CONSTRUCTION PROCEDURES .....	3-4
A. Pitot Tube (Optional) .....	3-4
B. Installing the Marker Beacon Antenna (Optional) .....	3-5
C. Communications Antenna (Optional) .....	3-5
D. Spar Closeout .....	3-6
E. Main Gear Doors .....	3-7
Fitting the Gear Doors .....	3-8
Gear Doors - Release Tape (Optional) .....	3-9
Gear Doors - Outboard Hardware Mounting .....	3-11
Gear Doors - Installing the Outboard Attachment Receptacles .....	3-11
Installing the Inboard Gear Door .....	3-12



Lancair International Inc., Represented by Neico Aviation Inc., Copyright © 2000, Redmond, OR 97756

TOC-I	REV.	3/12-15-04
<b>Table of Contents</b>		

F.	Main Gear Installation .....	3-15
G.	Main Gear Wheels and Tires .....	3-21
H.	Center Wing Section Hydraulics .....	3-24
I.	Aft Spar Transition Holes .....	3-31
J.	Landing and Taxi Lights (Optional) .....	3-32
K.	Speed Brakes (Optional) .....	3-35
L.	Fuel and Hydraulic Lines Schematics .....	3-36

## Chapter 4: Fuel Systems ..... 4-1

1.	INTRODUCTION .....	4-1
2.	PARTS LIST .....	4-1
3.	CONSTRUCTION PROCEDURES .....	4-3
A.	Legacy Fuel System - General Overview .....	4-3
B.	Fuel Selector Valve (Optional) .....	4-4
C.	Fuel Supply Lines .....	4-5
D.	Fuel Vent Line Check Valve .....	4-8
E.	Fuel Return Lines .....	4-9
F.	Fuel Probe (Optional) .....	4-10
G.	Fuel Boost Pump (Optional) .....	4-10
H.	Fuel Drain Covers .....	4-12

## Chapter 5: Outboard Wing Section Installation ..... 5-1

1.	INTRODUCTION .....	5-1
2.	PARTS LIST .....	5-1
3.	CONSTRUCTION PROCEDURES .....	5-2
A.	Wing Installation and Removal .....	5-2

## Chapter 6: Aileron Controls ..... 6-1

1.	INTRODUCTION .....	6-1
2.	PARTS LIST .....	6-1
3.	CONSTRUCTION PROCEDURES .....	6-3
A.	Control Stick Installation .....	6-3
B.	Aileron Controls Rigging .....	6-4

C.	Counterbalancing Ailerons .....	6-8
D.	Aileron Trim System .....	6-9
	How the Trim System Works .....	6-9
	Instructions for Adjusting the Aileron Trim Servo .....	6-9

## Chapter 7: Aircraft Alignment Jig ..... 7-1

1.	INTRODUCTION .....	7-1
2.	PARTS LIST .....	7-1
	Supplies List .....	7-1
3.	CONSTRUCTION PROCEDURE .....	7-3
A.	Wing Jig .....	7-3
	Alignment Criteria .....	7-6
B.	Aft Fuselage Jig .....	7-7
C.	Vertical Tail Supports .....	7-11

## Chapter 8: Outboard Wing Section Closing ..... 8-1

1.	PARTS LIST .....	8-1
2.	CONSTRUCTION PROCEDURES .....	8-2
A.	Closing the Wings .....	8-2
	Understanding the Relative Percentage Chordline... ..	8-5
B.	Pressure Testing the Wings .....	8-9
	Fixing a Leak .....	8-9
C.	Strobe and Nav Lights .....	8-10

## Chapter 9: Canopy ..... 9-1

1.	INTRODUCTION .....	9-1
2.	PARTS LIST .....	9-1
3.	CONSTRUCTION PROCEDURES .....	9-3
A.	Canopy Latch Mechanism .....	9-3
B.	Canopy Stiffener Alignment .....	9-9
C.	Canopy Hinge .....	9-17
	Alignment .....	9-17
D.	Gas Strut .....	9-23
E.	Canopy Stricker Metchanism .....	9-26



F.	Canopy Alignment Mechanism .....	9-30
G.	Windshield Installation .....	9-32
	Canopy Alignment .....	9-32
H.	Canopy Defroster .....	9-35
I.	Canopy Skin Bonding .....	9-37
J.	Canopy Seal .....	9-39
	Proper Orientation .....	9-39

## Chapter 10: Center Wing Section Installation ..... 10-1

1.	PARTS LIST .....	10-1
2.	CONSTRUCTION PROCEDURES .....	10-2
A.	Bonding the Center Wing Section .....	10-2
B.	Installing Load Pads .....	10-12
C.	Installing the Aft Closeout Rib .....	10-14
D.	Closing the Center Wing Section .....	10-15

## Chapter 11: Horizontal Tail Installation ..... 11-1

1.	INTRODUCTION .....	11-1
2.	PARTS LIST .....	11-1
3.	CONSTRUCTION PROCEDURES .....	11-2
A.	Bonding the Horizontal Stabilizer .....	11-2
	Trimming the Left Vertical Skin .....	11-2
	Proper Horizontal Stabilizer Installation during Bonding .....	11-3
B.	Vertical Web Installation .....	11-5

## Chapter 12: Vertical Closeout ..... 12-1

2.	PARTS LIST .....	12-1
3.	CONSTRUCTION PROCEDURES .....	12-2
A.	Counterweight Installation .....	12-2
B.	Left Vertical Skin Installation .....	12-3
	Typical Vertical Tail Cross Section .....	12-3
C.	Elevator Weldment Access Panel .....	12-7
D.	Bonding the Vertical Stabilizer .....	12-8

## Chapter 13: Firewall Forward ..... 13-1

1.	INTRODUCTION .....	13-1
2.	PARTS LIST .....	13-1
3.	CONSTRUCTION PROCEDURES .....	13-3
A.	Firewall Closeout .....	13-3
B.	Firewall Flame Blanket .....	13-5
C.	Engine Mount Installation .....	13-10
	Mounting Holes #1 - 5 .....	13-10
	Nose Gear Brace Mounts .....	13-10
	Mounting Holes #1 - 5 .....	13-11
	Nose Gear Brace Mounts .....	13-11
D.	Nose Gear Installation .....	13-12
	Left Side View .....	13-13
E.	Nose Wheel and Tire .....	13-15
F.	Nose Gear Doors .....	13-17
G.	Nose Gear Micro Switch .....	13-26
	Nose Gear Down Switch .....	13-26

## Chapter 14: Center Console ..... 14-1

1.	INTRODUCTION .....	14-1
2.	PARTS LIST .....	14-1
3.	CONSTRUCTION PROCEDURE .....	14-2
A.	Center Console .....	14-2
	Glove Box .....	14-3
	Glove Box Lid .....	14-4
B.	Fitting the Center Console .....	14-6
C.	Seat Belt Reinforcement .....	14-8
D.	Forward Access Panel .....	14-9
E.	Dump Valve Mounting .....	14-10
F.	Throttle - Prop - Mix .....	14-12
G.	Fuel Selector Valve Handle .....	14-13
H.	Center Console Bonding .....	14-14

**Chapter 15: Seats & Seat Belts ..... 15-1**

- 1. INTRODUCTION ..... 15-1
- 2. PARTS LIST ..... 15-1
- 3. CONSTRUCTION PROCEDURES ..... 15-2
  - A. Fitting the Seat Pans ..... 15-2
  - B. Outboard Seat Supports ..... 15-3
  - C. Center Seat Supports ..... 15-4
  - D. Installing the Seat Belts ..... 15-5

**Chapter 16: Hydraulic Systems Completion ..... 16-1**

- 1. INTRODUCTION ..... 16-1
- 2. PARTS LIST ..... 16-2
- 3. CONSTRUCTION PROCEDURES ..... 16-3
  - A. Hydraulic Lines - Aft of Aft Spar ..... 16-3
  - B. Hydraulic Lines - Forward of Main Spar ..... 16-7
  - C. Adjusting the Inboard Main Gear Doors ..... 16-10
    - Trimming the Sleeve to Length ..... 16-11
    - Adjusting the Inboard Main Gear Doors ..... 16-11
  - D. Setting the Main Gear 'UP' Stop ..... 16-12
    - Setting the 'UP' Stop ..... 16-12
  - E. Adjusting the Outboard Main Gear Doors ..... 16-13
  - F. Gear Switch and Lights ..... 16-14
    - Gear Transition Light ..... 16-14
    - Gear Down Lights ..... 16-15
  - G. Gear Micro Switch Wiring ..... 16-16
  - H. Gear Pressure Switch Wiring ..... 16-17
  - I. Gear Wiring Schematic ..... 16-18
  - J. Hydraulic Gear Start Up and Test Operations ..... 16-19
    - Adding Hydraulic Fluid ..... 16-19
    - Start up of the Hydraulic Gear ..... 16-19
  - K. Pressure Switch Adjustment ..... 16-21
  - L. Free Fall Test ..... 16-21
  - M. In-flight Free Fall Testing ..... 16-22
  - N. Hydraulic Pump Conversion (Optional) ..... 16-23

**Chapter 17: Rudder Completion ..... 17-1**

- 1. INTRODUCTION ..... 17-1
- 2. PARTS LIST ..... 17-1
- 3. CONSTRUCTION PROCEDURES ..... 17-3
  - A. Trimming the Rudder ..... 17-3
  - B. Rudder Leading Edge Closeout ..... 17-5
  - C. Rudder Trim System (Optional) ..... 17-10
  - D. Adjusting the Rudder Counter Weights ..... 17-13
  - E. Rudder Pedal Installation ..... 17-14
  - F. Floorboard Installation ..... 17-19
    - Version 1 ..... 17-19
    - Version 2 ..... 17-21
  - G. Rudder Bellcrank ..... 17-25
  - H. Rudder Pushrod ..... 17-26
  - I. Rudder Cable ..... 17-27
    - Adjusting the Pedal Position Aft ..... 17-32
    - Adjusting the Pedal Position Forward ..... 17-32

**Chapter 18: Brake System ..... 18-1**

- 1. INTRODUCTION ..... 18-1
- 2. PARTS LIST ..... 18-1
- 3. CONSTRUCTION PROCEDURES ..... 18-2
  - A. Brake System ..... 18-2
  - B. Installing the Brake Assemblies ..... 18-3
  - C. Filling and Bleeding the Brakes ..... 18-6



Lancair International Inc., Represented by Neico Aviation Inc., Copyright © 2000, Redmond, OR 97756

TOC-IV	REV. 3/12-15-04
Table of Contents	

<b>Chapter 19: Elevator Controls .....</b>	<b>19-1</b>
1. INTRODUCTION .....	19-1
2. PARTS LIST .....	19-1
3. CONSTRUCTION PROCEDURES .....	19-2
A. Elevator Controls Rigging .....	19-2
Control Stick .....	19-4
Elevator Idler Arm .....	19-4
Elevator .....	19-4
B. Trimming Inboard Ends for the Rudder .....	19-5
<b>Chapter 20: Instrument Panel .....</b>	<b>20-1</b>
1. INTRODUCTION .....	20-1
2. PARTS LIST .....	20-1
3. CONSTRUCTION PROCEDURES .....	20-2
A. Instrument Panel Installation .....	20-2
B. Dust Cover .....	20-6
Trimming the Dust Cover .....	20-7
C. Avionics Mounting Shelf .....	20-8
D. Typical Panels .....	20-9
<b>Chapter 21: Flap System Completion .....</b>	<b>21-1</b>
1. INTRODUCTION .....	21-1
2. PARTS LIST .....	21-1
3. CONSTRUCTION PROCEDURES .....	21-3
A. Center Torque Tube Support .....	21-3
B. Flap Installation .....	21-7
C. Flap Motor Installation .....	21-9
Flap Motor Alignment .....	21-10
Flap Adjustments .....	21-10
D. Bonding the Wing Trailing Edge .....	21-11

<b>Chapter 22: Cabin Ventilation .....</b>	<b>22-1</b>
1. INTRODUCTION .....	22-1
2. PARTS LIST .....	22-1
3. CONSTRUCTION PROCEDURES .....	22-2
A. Fresh Air (Unheated) .....	22-2
B. Cabin Heat*/Cabin Defroster* .....	22-3
<b>Chapter 23: Baggage Compartment .....</b>	<b>23-1</b>
1. INTRODUCTION .....	23-1
2. PARTS LIST .....	23-1
3. CONSTRUCTION PROCEDURE .....	23-3
A. Control Tube Cover .....	23-3
B. Bulkhead Cover .....	23-5
C. Overhead Console* .....	23-6
D. Floorboards* .....	23-7
Installing Floorboard Access Panels .....	23-8
E. Oxygen System (Optional) .....	23-15
<b>Chapter 24: Miscellaneous Systems .....</b>	<b>24-1</b>
1. INTRODUCTION .....	24-1
2. PARTS LIST .....	24-1
3. CONSTRUCTION PROCEDURES .....	24-2
A. Pitot Static System .....	24-2
Static Port Installation .....	24-3
B. ELT Installation .....	24-4
C. Storm Scope Installation* .....	24-5
D. Transponder Antenna Installation .....	24-6

**Chapter 25: Aft Windows ..... 25-1**

- 1. INTRODUCTION ..... 25-1
- 2. PARTS LIST ..... 25-1
- 3. CONSTRUCTION PROCEDURE ..... 25-2
  - A. Preparing the Fuselage Shell ..... 25-2
  - B. Preparing the Windows ..... 25-3
  - C. Window Installation ..... 25-5

**Chapter 26: Firewall Forward (part 2) Continental 550 ..... 26-1**

- 1. INTRODUCTION ..... 26-1
- 2. PARTS LIST ..... 26-1
- 3. CONSTRUCTION PROCEDURES ..... 26-4
  - A. Mounting the Engine ..... 26-4
  - B. Propeller/Spinner ..... 26-5
  - C. Cowling ..... 26-6
  - D. Baffling ..... 26-9
  - E. Engine Control Systems ..... 26-22
  - F. Manifold Pressure and Tachometer ..... 26-25
    - Tachometer ..... 26-25
  - G. Fuel Systems ..... 26-26
  - H. Oil Systems ..... 26-33
    - Oil Temperature Sensor ..... 26-33
    - Oil Pressure Sensor ..... 26-33
  - I. Vacuum System Installation (Optional) ..... 26-35

**Chapter 27: General Wiring ..... 27-1**

- 1. INTRODUCTION ..... 27-1
- 2. PARTS LIST ..... 27-2
- 3. CONSTRUCTION PROCEDURES ..... 27-3
  - A. Basic Wiring Techniques ..... 27-3
  - B. Legacy General Wiring ..... 27-4
  - C. Basic Aircraft Wiring ..... 27-6
  - D. Landing Gear Wiring ..... 27-7

- E. Lights Wiring ..... 27-8
- F. Electric Fuel Pump ..... 27-10
- G. Trim System Wiring ..... 27-11
- H. Flap Wiring ..... 27-13
  - Setting the Flap Limit Stops ..... 27-15
- I. Pitot Tube Heat Wiring ..... 27-16
- J. Electric Door Seal Wiring ..... 27-16
- K. Antenna Placement ..... 27-17

**Chapter 28: Finishing Techniques ..... 28-1**

- 1. INTRODUCTION ..... 28-1
  - Painting and Interiors ..... 28-1
- 2. PARTS LIST ..... 28-1
- 3. CONSTRUCTION PROCEDURES ..... 28-2
  - A. Bid Tapes ..... 28-2
  - B. Mixing Micro ..... 28-2
  - C. General Surface Preparation ..... 28-2
  - D. Priming Materials ..... 28-3
  - E. Paint Preparations ..... 28-4
  - F. Painting ..... 28-4
  - G. Base Colors ..... 28-4
  - H. Trim Colors ..... 28-5



Lancair International Inc., Represented by Neico Aviation Inc., Copyright © 2000, Redmond, OR 97756

TOC-VI	REV. 3/12-15-04
<b>Table of Contents</b>	